

PMR Frequencies Channel Frequency in MHz

Channel Number	Frequency
1	446.00625 MHz
2	446.01875 MHz
3	446.03125 MHz
4	446.04375 MHz
5	446.05625 MHz
6	446.06875 MHz
7	446.08125 MHz
8	446.09375 MHz

PMR Radio CTCSS Frequency List

Sub Channel	Tone Frequency (Hz)	Sub Channel	Tone Frequency (Hz)
1	67.0Hz	20	131.8 Hz
2	71.9 Hz	21	136.5 Hz
3	74.4 Hz	22	141.3 Hz
4	77.0 Hz	23	146.2 Hz
5	79.7 Hz	24	151.4 Hz
6	82.5 Hz	25	156.7 Hz
7	85.4 Hz	26	162.2 Hz
8	88.5 Hz	27	167.9 Hz
9	91.5 Hz	28	173.8 Hz
10	94.8 Hz	29	179.9 Hz
11	97.4 Hz	30	186.2 Hz
12	100.0 Hz	31	192.8 Hz
13	103.5 Hz	32	203.5 Hz
14	107.2 Hz	33	210.7 Hz
15	110.9 Hz	34	218.1 Hz
16	114.8 Hz	35	225.7 Hz
17	118.8 Hz	36	233.6 Hz
18	123.0 Hz	37	241.8 Hz
19	127.3 Hz	38	250.3 Hz